CARE AND CLEANING

Recommended procedures

DO NOT use harsh chemicals.

DO NOT spray liquids on the screen.

DO NOT accelerate cooling of the oven by using water or ice.

DO NOT use cleaning products that are corrosive or that contain ammonia, phosphates, chlorine, potassium or sodium hydroxide (caustic soda).

DO NOT use pressure cleaning systems.

DO NOT spray cleaner into the holes.

DO NOT use abrasive sponges to clean the cover of the upper surface of the cooking compartment

DO NOT cook food wrapped in plastic wrapping.

DO NOT use the oven if the air filters are not in place.

DO NOT operate the oven empty in microwave mode.

DO NOT apply weights greater than 5 kg or lean against the open door. Risk of damage to or overturning of the oven.

- **Below is the table of the scheduled and preventive maintenance plan.**

COMPONENT	FREQUENCY	ACTION
Oven and accessories	Daily	Wash the oven and accessories daily or as required according to the instructions in the manual.
Inlet air filters	Weekly	clean the magnetic air filters with water and neutral detergent
Internal air filter	100,000 cycles	When changing the magnetrons, clean the air expulsion grille in the back of the oven.
Electric contactor	100,000 cycles	Replace the component with original spare parts. The oven contains an internal counter that stores the number of activations. At the end of the recommended cycles, it will show a maintenance recommendation notification.

CARE AND CLEANING

DAILY CLEANING:

1. PREPARE OVEN

1. Shut oven off by pressing ON/OFF button. The fan will run for a few minutes to cool the oven interior faster. Let the oven interior reach room temperature before cleaning.

   Note:*To accelerate cool down time of oven, put a tray filled with ice in oven cavity after shutting the oven down.*

2. Once cooled, remove cook plate and other accessories from the cavity.

2. CLEAN OVEN INTERIOR

FOR OVENS WITH NON-STICK LINERS

1. Using a warm, damp, clean towel, wipe the oven interior. Rinse the towel and wring dry. Repeat 2-3 times to remove remaining particles from the oven.
2. **FOR STUBBORN DEBRIS**, use OSOCL oven cleaner:
   a. Wear rubber gloves and safety glasses. Spray oven door and cavity with OSOCL oven cleaner. Avoid spraying into perforations. Allow cleaner to soak for 2 minutes.
   ⚠ **DO NOT spray cleaning solution into perforations.**
   b. **WIPE OVEN INTERIOR.** Using a damp clean towel, wipe the oven interior, then rinse the towel and wring dry. Repeat 2-3 times to remove remaining oven cleaner and particles from the oven.

2. CLEAN OVEN INTERIOR

FOR OVENS WITHOUT NON-STICK LINERS

1. Wear rubber gloves and safety glasses.
2. **CLEAN OVEN INTERIOR:** Spray oven door and cavity with OSOCL oven cleaner.
   ⚠ **DO NOT spray cleaning solution into perforations.** Allow cleaner to soak for 2 minutes.
   a. Clean metal portions of the oven door and interior using a plastic scouring pad.
   b. Clean cavity ceiling cover with a damp cloth sprayed with cleaner and apply gentle pressure to clean cavity ceiling cover.
   c. Clean perforated area with damp cloth sprayed with cleaner.
3. **WIPE OVEN INTERIOR.** Using a damp clean towel, wipe the oven interior, then rinse the towel and wring dry. Repeat 2-3 times to remove remaining oven cleaner and particles from the oven.
4. **APPLY OVEN SHIELD.** When oven is clean, spray a thin layer of OSOPR Oven Shield on all interior surfaces. Do not remove OSOPR.

3. CLEANING ACCESSORIES

1. **CLEANING THE OVEN TRAY:** Allow the oven tray to cool before cleaning.
   a. Clean the oven tray with washing up liquid and a non-abrasive sponge or soft bristle brush.
   b. **FOR STUBBORN DEBRIS,** leave the oven tray to soak in hot, soapy water for 10 minutes. Burnt-on foods should lift off after soaking. Then, proceed with the detergent and plastic scouring pad, being sure to rinse thoroughly.
   ⚠ **Do NOT use caustic cleaners (e.g. sodium hydroxide) as they react with aluminium and will degrade the surface.**
2. For other accessories, please refer to instruction sheet included in original packaging.

4. CLEAN OVEN EXTERIOR

1. **CLEAN EXTERIOR DOOR** and other surfaces with a clean cloth, sponge or nylon pad; using a mild detergent and warm water solution.
2. **CLEAN THE TOUCHSCREEN** with a dry or damp microfibre cloth.
   ⚠ **Do NOT use harsh chemicals. Do NOT spray liquid on the screen.**

WEEKLY CLEANING

1. CLEAN AIR FILTERS

1. Remove all 3 of the magnetic air filters located along the front base and sides of the oven.
   ⚠ **WARNING: Do NOT operate oven without air filters in place.**
2. Wash filters in a mild detergent solution made with warm water.
3. Rinse and dry thoroughly.
4. Place the clean filters on oven front base and sides.