INSTRUCTION SHEET 16200118

Description: Oven Basket (OB10, TB10S, SB10S, MB10S)

Item	Dimensions	Quantity Included in Kit
OB10	13.5" x 13.5"	1
TB10S	11" x 11"	2
SB10S	5.5" x 11"	2
MB10S	5.5" x 5.5"	2

Oven Basket Care and Usage Instructions:

Usage:
Baskets should not be stored in the oven!

Handling:
Oven baskets can be used from -100°F (-73°C) to 550°F (288°C). Check to ensure Oven Basket is dry and clean before placing any food on it. It can be used in all types of ovens and does not need to be oiled or greased.

Removing Oven Basket:
Always remove basket from oven with paddle. Never handle the basket out of the oven, as basket will be hot.

Removing From Oven Basket:
After baking or cooking, remove by gently lifting product out of the basket. Never use sharp utensils of any type to lift or remove product from the basket.

Maintenance and Care:
The oven basket must be cleaned on a regular basis. If not cleaned regularly, food particles become carbonized in the PTFE coated fibers of the basket. Over time, this can cause the PTFE lining to degrade, exposing worn fibers. When worn or frayed fibers are visible, replace the Oven Basket accessory immediately.

PTFE coated materials are easily cleaned. Typically, wiping with a damp soft cloth and warm water will clean the PTFE fabric sufficiently. We recommend a cotton cloth or dishtowel. The materials are unaffected by most commercial and industrial cleaning solvents and chemicals used to keep food contact surfaces clean. Do not use scrubbing pads, scrapers or hard brushes to clean. Do not place baskets in dishwasher. Shake off excess water and lay flat to dry. Do not submerge or soak baskets in water.

Storing:
Store Oven Baskets flat on a tray or shelf, not in hot oven. Do not fold, roll up or store items on top of the baskets.

Precautions:
Never cut or use sharp objects and utensils on the surface.
Never scrape the PTFE coating off the substrate.
Do not fold.
Do not grease.
Do not store baskets in hot oven.