QUICK REFERENCE GUIDE:
MODELS 406-AN and 398-CN DISPENSERS

Please follow these tips to get the best performance from your Ketchup and Mustard Dispensers

Assembly:



Install and replace piston rings and springs by hand, do not use tools or sharp objects. Mustard piston ring shown.



Make sure spring is snapped onto piston rod

Priming:

Fill with ketchup or mustard without lever installed.



With a clean and empty dispenser add ketchup or mustard BEFORE installing lever. If dispenser has run out of sauce during use it can be refilled without removing lever.





Washing:

HAND WASH PARTS ONLY! DO NOT PUT PARTS IN DISHWASHER OR POWER SOAK.

Read Operation Manual for full details on use and care of dispensers.

Printed in USA 12/17 ©2017

355 East Kehoe Blvd. • Carol Stream, IL 60188 USA
Telephone: 630-462-8800 • Toll Free: 1-800-PCASTLE